

Vacuum Removal Instructions

ITEMS INCLUDED:

- 2 3 1/2" Magnets
- 2 Rubber Magnet covers
- 1 1/4-20 Finish Hex Nut (SS)
- 2 1/4-20x7/8" button-head bolt (SS)
- 2 1/4-20 KEPS Locknut (SS)

Carefully remove the 3/8" plug from the top center of the rod transport frame using your fingernails or a knife blade.



Now remove the vacuum assembly from the frame using a 3/16" hex driver placed through the top center of the rod transport frame.



Next remove the 1/4" washer found between the frame bottom and the vacuum assembly.



Using the 1/4-20 Finish Hex Nut provided, re-secure the frame assembly.



Install the Magnets using the 1/4-20x7/8" button-head bolts and the 1/4-20 KEPS Locknuts provided. This requires a 7/16" socket and a 5/32" hex wrench.

Replace the 3/8" plug and the rod transport has been converted from Vacuum to Magnetic.

Contact Information:

9014 South Gary Ave., Tulsa, OK 74137-3313
Ph: 918-706-4396 - Fax: 918-299-2712
E-mail: wlwfisher@aol.com